


SANAKO LAB 100 STUDENT QUICK REFERENCE GUIDE

USER AUDIO PANEL

Recorder Controls

The recorder controls of the User Audio Panel are under teacher's control. The teacher disables the controls on the student panels by setting the locked mode.





Function keys

CALL TEACHER

Press to call teacher.
Press again to cancel the call.

Bookmark number keys

- Set bookmarks
- Search for bookmarks
- Remove bookmarks
- Answer a Quiz question
- Dial a phone number
- Select/change a file in Audio-on-Demand

TRUE / FALSE

Press to answer a Quiz question.



STUDENT WORKSTATION NUMBER

MODE

To repeat a loop of audio between two Bookmarks hold down Mode and press the appropriate Bookmarks. To switch repeat off hold down the Mode key and press Clear.

VOLUME CONTROLS

Set the volume for the audio source and the student.

CLEAR

Clear the PIN code or phone number in AP® Exam and Phone Conversation

User Audio Panel Display

